

Comparison Table

	GiSTEQ PhotoTrackr™	SONY GPS-CS1
Camera Compatibilities	Support ALL digital cameras	Bundled mapping program only supports certain Sony models that comes with CyberShot "Picture Motion Brower"
Data Storage	4MB Flash, store up to 250K data records, about a month under normal usage	Up to one month for 12 hours/day
How soon can I start tracking after I turn on the device	Cold Boot: 45 sec Warm Boot: 38 sec Hot boot: 6 sec	44-45 seconds
Logging Interval	Logging data interval programmable– - by distance: 2 ~ 65535 meters - by time: 1 second ~ 30 minutes	Only by distance every 15 sec
Connection to PC	USB	USB
USB Powered	Yes	Yes
Clock Synchronization function	Yes	No
Display Historical Trip Routes	Yes	No
Playback Historical Trip Routes	Yes	No
Organize Historical Trips	Yes	No
Manage Logger Owner	Yes	No
Display maps on Google Maps worldwide	Yes	Yes
Integrated with Flickr™ Online Photo Sharing	Yes	No
Display Detail Photo Address Location & Coordinate	Yes	Only Coordinates
Power Saving with Vibration Sensor	YES, auto power on/off. Sensor time limit manually adjustable.	No
Waypoint Tagging	Yes, remember any points of interest using the tag button	No
Memory Usage Status Gauge	Yes, via the supplied software	No
GPS Channels	16 Channels	12 Channels
Build-in Speaker	Yes, with voice alert about satellite fix status, battery low warning and audio feedback for every operation.	No
Rechargeable Battery	Yes, built-in re-chargeable Li-ion battery, 1100mAh	No, 1 x AA battery

Battery Life	32 hours continuous use	10 – 14 hours continuous use
Daylight Saving	Manually adjustable (Automatic adjusted if system time is updated)	Manually adjustable
Compatible OS	WinXP, Windows Vista	WinXP, ME, 2000
Weight	2.2oz	2oz
Dimension (inches)	3.05 (L) x 1.82 (W) x 0.89 (H)	3 1/2 x 1 7/16 x 1 7/16
MSRP	US\$ 129.00	US\$149.00